

Final Installation



Hood Strut Kit 2005-2014 Ford Mustang Installation Guide



Included in the Kit:

2-Struts

2-Large Upper Brackets

2-Small Lower Brackets



STEP 1 - Open Hood and wrap corner with towel to protect hood, fender, and cowl



STEP 2 - Install lower strut mount on drivers side using existing bolt as pictured



STEP 3 - Install lower strut mount on passenger side using existing bolt as pictured



STEP 4 - Place masking tape alongside upper hood hinges and mark location of bolts to ensure proper hood realignment



STEP 5 - Loosen upper hood hinge bolt with a while a friend holds hood in place



STEP 6 - Remove front bolt and insert upper bracket under rear bolt and reinstall front bolt



STEP 7 - Repeat steps 1-6 for opposite side



STEP 8 - Snap strut in place on passenger side



STEP 9 - Snap strut in place on driver side and installation is finished

